



2000 SERIES ENGINE TROUBLESHOOTING

Follow these preliminary tests if you think there is a problem with your engine heater.

NOTE: The heater is controlled by an internal electronic motherboard. If there is no code displayed, the fault is probably a connection issue and not a heater issue.

Checks:

1. Check battery voltage. (need 11v or more to operate)
2. Check if water pump is operating.
3. Ensure cooling system does not have an air lock.
4. Check heating performance by connecting the outlet hose to the inlet hose and perform a heat operation test.

If all these tests are performed and the heater achieves approx. 175*, the heater is functioning correctly.